

GETTING STARTED WITH YOUR NEW CSTM80 KEYBOARD

INITIAL START-UP

- The keyboard should work out of the box with macOS, Windows and Linux operating systems.
- For CSTM80 customizability instructions, please scan the QR code or visit dro.ps/cstm80-quickstart



DEFAULT HOT KEYS

Hold Fn key + listed keys to activate

LED KEYS

Fn +	W	LED Brightness Increase
	S	LED Brightness Decrease
	E	LED Animation Speed Increase
	D	LED Animation Speed Decrease
	R	LED Hue Increase
	F	LED Hue Decrease
	T	LED Saturation Increase Off)
	G	LED Saturation DecreaseToggle
	Q	LED Toggle (On / Off)
	A	LED Animation Toggle
	Z	LED Mono Color Mode
	X	LED Breathing Effect
	C	LED Rainbow Mode
	V	LED Rainbow Pinwheel Modezz

MISC CONTROL

Hold Esc (Before connecting USB)	Boot Magic (Clear EEPROM State and reboot in Bootloader)
-------------------------------------	----------------------------------------------------------

KEYBOARD OPTION KEYS

Fn +	N	Toggle keyboard 6KRO/NKRO (Default state is 6KRO)
	LCtrl+O	Windows / MacOS Swap (System / Alt location change)
	LCtrl+ \ Backspace	LCtrl / Capslock Swap
	LCtrl+Backspace	Reset Keyboard

CUSTOMIZABLE FIRMWARE

To configure your keymap and hotkeys, please visit: dro.ps/cstm-configurator

