


 When printing the Drilling Template at home, please make sure that the print size is 100% (file size = print size).  
Therefore deactivate "automatic page scaling" in the print dialog for example."

## bottom view



## right side view

