
CSW V2 without Adapter

FANATEC



When printing the Drilling Template at home, please make sure that the print size is 100% (file size = print size). Therefore deactivate "automatic page scaling" in the print dialog for example."

bottom view



right side view

